
S-VHS SERVICE_PLUG
FRONT AV IN
AUDIO OUTPUT
IC100*
TDA2614_MONO
TDA2615_STEREO
PL900*
NAME
TU201*
AUDIO SWITCH
STEREO DECODER BOARDS SOCKETS
TDA9830
IC402*
SECAM-L' & AM DEMOD
VIDEO SWITCH
IC050*
TEA6415C
VIDEO PROCESSOR
VERTICAL OUTPUT
IC701*
TDA8351_110
TEXT & CONTROLLER
IC401*
TDA884X
IC502
24C08
IC501*
TDA52XX
IC801*
MPS19
YUV INTERFACE SOCKET
* THE WIRES TO CONTROL PCB MUST BE ZIP TIED TOGETHER AGAIN AFTER ANY KIND OF REPAIREMENT
* OPTIONAL COMPONENT
11AK19 MAIN CHASSIS